

Assembly manual

Waste bin housing



Step 1

Insert the back panel into the bottom frame



Step 2

Insert the two side panels and screw them to the back panel.



Step 3

Insert the two side panels and fasten them to the back panel with screws.



Step 4

Screw the base frame together



Step 5

Attach the lid



Step 6

Install hydraulic cylinders and front doors

