

PureNature assembly instructions

1. Transport

Due to their low weight, PureNature wooden plant supports can be transported in large quantities on your arms to the plantation.



2. Inserting the support rod

The support rod (150 cm long) is placed approx. 5 cm next to the plant. It is driven approx. 30 cm into the ground.



3. Attaching the wooden wall

The wooden wall marked "1" is positioned with the plug wood facing outwards on the support rod so that a distance of approx. 10 cm from the ground is maintained. We recommend using a cordless stapler to attach the wooden wall to the support rod.



4. Insert wooden walls

The sturdy wooden walls are connected to each other around the tree in the marked order using two stabilizing pieces of wood with a plug connection. Please note that the stabilizing pieces of wood are connected to each other with tongue and groove joints.



EcoTrade Leipzig GmbH cannot be held liable for damage to this product caused by incorrect installation or misuse. Failure to observe the installation /load recommendations does not constitute grounds for complaint.