

Installation Recommendation

New paddock installation

- Step 1** Remove non-load-bearing soil and create a stable subgrade.
- Step 2** Cover the entire area with a suitable geotextile (arranged with overlapping).
- Step 3** Then apply the base course. This should consist of 10–15 cm of permeable material (e.g., gravel with a grain size of 8–32 mm) and leveled with appropriate equipment.
- Step 4** Finally, level the surface with a layer of fine aggregate (2–5 mm grain size) (leveling). The leveling layer should be approximately 2–3 cm thick.
- Step 5** Next, begin laying the tiles. Start in a corner, leaving at least a 5 cm gap from the edge.
- Step 6** Finally, apply the wear layer using washed sand (0–2 mm grain size) or similar. This layer should be 3–4 cm thick.

Installation of Riding Arena

- Step 1** Apply a gravel leveling layer to the existing subgrade (5–8 mm grain size). This layer should be 4–5 cm thick.
- Step 2** Next, begin laying the tiles. Start in a corner, leaving at least 5 cm of space from the edge.
- Step 3** Finally, apply the walking surface layer of washed sand (grain size 0–2 mm) or similar. This layer should be 8–10 cm thick.

Installing the lawn

- Step 1** Remove unstable soil and create a stable subgrade.
- Step 2** Next, begin laying the tiles. Start in a corner at least 5 cm away from the edge.
- Step 3** Fill the turf grid with a sand/soil mixture and then the area.

EcoTrade Leipzig GmbH cannot be held liable for damage to this product caused by improper installation or incorrect use. Failure to follow the installation /load recommendations does not constitute grounds for a complaint.